


Calibration Method – Linear regression

• Do linear regression for both IMU A6 and 1A with EM tracker using samples data






Mock OR Data Analysis – rotate to left & right



Rotate to left


 Roll angle changes between 0 degree to 80 degree periodically.



- Rotate to right
 - Roll angle changes between -80 degree to 20 degree periodically.
 - Pitch angle and Yaw angle change little and there is no significant difference between left and right circumstances.


Coordinate system figure from: https://stanford.edu/class/ee267/lectures/lecture10.pdf

Mock OR Data Analysis – turn to left & right



Turn to left

 Yaw angle changes between -10 degree to 45 degree periodically.





- Turn to right
- Yaw angle changes between -60 degree to 5 degree periodically.
- Pitch angle and Roll angle change little and there is no significant difference between left and right circumstances.

Coordinate system figure from: https://stanford.edu/class/ee267/lectures/lecture10.pdf

Mock OR Data Analysis – turn up and down


- Pitch angle changes between -80 degree to 80 degree strongly and periodically.
- Yaw angle and Roll angle changes little.






Mock OR Data Analysis – rotate circle


- Pitch angle and Yaw angle change in a circle.
- Roll angle changes randomly.






Mock OR Data Analysis – move shoulder


Pitch angle, Yaw angle, and Roll angle change little (almost zero degree).





Mock OR Data Analysis – traditional case

- Pitch angle keeps at 85 to 90 degree for a long time;
- Yaw angle and Roll angle change between 0 to 60 degree, but they are not we concern about.



Mock OR Data Analysis – endoscopic case

- Pitch angle keeps at 25 to 35 degree for a long time;
- Yaw angle changes between -20 to 0 degree, and Roll angle changes between 10 to 30 degree, but they are not we concern about.

